

Latitude SRL-P Instruction Manual

- [Latitude SRL-P Instruction Manual](#)

Latitude SRL-P Instruction Manual



ANSI	Z359.14-2021
OSHA	1910.140, 1910.66

LATITUDE
PRO

SRL-P Instruction Manual



This manual is intended to meet the manufacturer's instructions as required by ANSI Z359.14-2021 and should be used as part of an employee training program as required by OSHA.

TABLE OF CONTENTS

1.0 INTRODUCTION	5
2.0 APPLICATION	5
3.0 APPLICABLE SAFETY STANDARDS	5
4.0 WORKER CLASSIFICATIONS	6
5.0 TRAINING.....	6
6.0 LIMITATIONS AND REQUIREMENTS	6
7.0 INSPECTION FREQUENCY	7
8.0 PURPOSE	7
9.0 SPECIFICATIONS	7
10.0 ACTUAL ARREST DISTANCE/MIN REQ FALL CLEARANCE	8-10
11.0 SWING FALLS	11
12.0 FALL PROTECTION AND RESCUE PLAN	12
13.0 NORMAL OPERATIONS	12
14.0 COMPATIBILITY OF COMPONENTS	12
15.0 COMPATIBILITY OF CONNECTORS.....	12-13
16.0 USE	13-15
17.0 PERFORMANCE	15
18.0 MAINTENANCE, SERVICE, AND STORAGE	15
19.0 INSPECTION	15-16
20.0 LABELING	16

User Information

Date of First Use: _____

Serial#: _____

Trainer: _____

User: _____

Do not throw away these instructions!

Read and understand these instructions before using equipment!

WARNINGS AND IMPORTANT PRECAUTIONS

User must read, understand, and follow all safety and usage information contained within this manual prior to use of this equipment. Failure to follow all safety and usage information can result in serious injury or death.

These instructions shall be provided to the user. User must read, understand, and follow all safety and usage information contained within this manual prior to use of this equipment. Failure to follow these instructions or improper use can result in serious injury or death.

Intended Use:

The equipment covered in this manual is intended for use as part of a complete Personal Fall Arrest System (PFAS).

Use of this equipment for any other purpose, such as material handling, sports activities, or other action not described in these User Instructions is not approved by Safewaze. Use of this equipment in a manner outside the scope of those covered within this Manual can result in serious injury or death.

The equipment covered in this manual is only to be used by trained personnel in workplace applications.



Safewaze Self Retracting Lifelines (SRLs) are part of a complete PFAS. Every user must be trained in the inspection, installation, operation, and proper usage of their complete PFAS. Unapproved or inappropriate use of Safewaze SRLs could result in serious injury or death. Refer to these instructions for the proper selection, installation, maintenance, and service of this equipment. For questions regarding use of this equipment beyond the scope of this manual, contact Safewaze.

• The warnings below are designed to reduce the risks associated with the use of Safewaze SRLs:

- User must inspect the SRL prior to each use which includes a check for proper locking and retraction.
- If the inspection reveals an unsafe or defective condition, the SRL must be removed from service and destroyed or repaired as specified in this manual.
- If a Safewaze SRL is exposed to fall arrest or impact forces, it must be immediately removed from service and tagged "Unusable".
- Never allow slack to form in the SRL lifeline constituent. Never tie or knot the lifeline.
- Utilize extra caution to keep the lifeline free from any obstructions including but not limited to; surrounding objects, tools, equipment, moving machinery, co-workers, yourself, or possible impact from overhead objects that could come into contact with the lifeline or worker.
- Avoid making sudden or quick movements as this could cause the SRL to inadvertently lock.
- Do not use a Safewaze SRL in an environment where the fall path is obstructed. Use of a Safewaze SRL on slowly shifting or unstable material such as grain or sand, or within cramped or confined spaces, may not allow the worker to reach adequate speed for the SRL lock up, resulting in possible engulfment.
- Work directly under the anchor point as much as possible to reduce risk of striking an object due to swing fall.
- Unused leg(s) of a harness mounted SRL must be attached to the parking component on the front of the harness.
- If the PFAS is made up of components from different manufacturers, ensure that all components of the PFAS are compatible with each other and meet all applicable standards, regulations, or requirements. A Competent or Qualified Person should always review and approve the PFAS system prior to worker use.
- Avoid lifeline contact with sharp or abrasive surfaces.
- DO NOT use combinations of components or subsystems, or both, that may affect or interfere with the safe function of each other
- DO NOT alter equipment
- DO NOT misuse equipment
- User must have a written Rescue Plan and means at hand to implement it when using this equipment. All employees should be trained and knowledgeable in the Rescue Plan and Rescue Operations.
- Avoid exposure of this equipment to chemicals, high heat, severe cold or other harsh environments which may produce a harmful effect. If in doubt about serviceability of this equipment, contact Safewaze.



• Users should enact the precautionary measures listed below to reduce the inherent risks of working at height:

- Fall protection equipment that fails inspection must be removed from service and tagged "Unusable". The equipment should then be returned to Safewaze for repair / service (if applicable) or destroyed. For questions regarding service / repair of components, contact Safewaze.
- Never exceed the maximum allowable weight capacity of your fall protection equipment.
- Never exceed the maximum free fall distance of your fall protection equipment.
- Only Safewaze, or entities authorized in writing by Safewaze, may make repairs to Safewaze fall protection equipment.
- User(s) of Safewaze fall protection equipment must ensure that their health and physical condition allows them to withstand all forces and potential risks associated with working at heights. ANSI limits the weight capacity of fall protection equipment to a maximum of 310 lbs. Some equipment covered in this manual may indicate a weight capacity in excess of 310 lbs. Although some equipment may be rated to a higher capacity, it should be noted that heavier users are at an increased risk of serious injury or death. This being due to increased forces on the body during a fall, and the risk for accelerated onset of suspension trauma.
- Use of a body belt is NOT authorized for fall arrest applications. Use only a Full Body Harness (FBH).
- Always wear required personal protective equipment when installing, using, or inspecting this equipment.
- If conducting training operations with this equipment, ensure that a secondary fall protection system is installed and utilized in a manner that does not expose the trainee to unintended fall hazards.
- Immediately seek medical attention in the event a worker suffers a fall arrest incident.
- Certain subsystems may interfere with the proper operation of the equipment in this manual. Use only compatible connections. Contact Safewaze for questions regarding compatibility of equipment or components not covered in this manual.
- Avoid objects, equipment, or surfaces that could harm the user or equipment.
- User must ensure that there is adequate fall clearance when working at height.
- Extra precautions must be taken if working in the vicinity of moving machinery, electrical hazards, chemical hazards, sharp edges, explosive or toxic gases, extreme temperatures, or below overhead equipment or materials that could impact the user and his/her fall protection equipment.
- If work is conducted in a high heat environment, ensure that Arc Flash or other suitable fall protection equipment is utilized.

TABLE 1 - LATITUDE PRO SRL-P CONFIGURATION TABLE



Standards: ANSI Z359.14-2021
OSHA 1910.140, 1910.66

Capacity: ANSI 130-310 lbs. (59-141 kg)
OSHA Up to 420 lbs. (191kg)

Part Number	CONNECTOR										ATTACHMENT																							
	Single Use (S) / Dual Use (D)	Working Length (ft)	SRL Class	Lifetime Material	Lifetime Dimensions (in.)	Housing Material	Connector										Attachment																	
							U-Steel Snap Hook ①	Steel Snap Hook ②	Delicate Snap Hook ③	Steel Tri-Bolt Hook ④	Steel Snap Hook ⑤	U-Steel Snap Hook ⑥	Steel Snap Hook ⑦	Steel Snap Hook ⑧	ALU Carbine Fire Carabiner ⑨	ALU Carbine Fire Carabiner ⑩	ALU Snap Carabiner ⑪	No Attachment	Tip Lock Steel Carabiner ⑬	Steel Carabiner ⑭	ALU Carabiner ⑮	ALU Carbine Ryc Carabiner ⑯	ALU Snap Hook ⑰	ES-9312 ⑱	Car Mount Bracket ⑲	Soft Loop ⑳	Integrated DWR ㉑	1014 DWR ㉒	9012 DWR ㉓	9013 DWR ㉔				
018-5000	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.2	X												X														
018-5001	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.0			X										X														
018-5002	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	3.2								X					X														
018-5003	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.8												X		X													
018-5004	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.8	X													X													
018-5005	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.6			X											X													
018-5006	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	3.8								X						X													
018-5007	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	3.4												X		X													
018-5008	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.7	X														X												
018-5009	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.5			X												X												
018-5010	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	3.7								X							X												
018-5011	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	3.3												X			X												
018-5012	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.5	X															X											
018-5013	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.3			X													X											
018-5014	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	3.5								X								X											
018-5015	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	3.1												X				X											
018-5016	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	5.4	X													X					X								
018-5017	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	5.0			X												X					X							
018-5018	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	7.4								X							X					X							
018-5019	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	6.6												X			X					X							
018-5020	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	5.2	X															X				X							
018-5021	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	4.8			X													X				X							
018-5022	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	7.2								X								X				X							
018-5023	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	6.4												X				X				X							
018-5024	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	4.8	X																									X	
018-5025	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	4.4			X																							X	
018-5026	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	6.8												X														X	
018-5027	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	6.0												X														X	
019-5124	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	4.9	X																								X		
019-5125	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	4.5			X																						X		
019-5126	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	6.9												X													X		
019-5127	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	6.1												X													X		
020-5269	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	5.9												X													X		
021-5288	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	4.3			X																							X	
018-5037	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	5.2								X																		X	
019-5137	1	D	7	Dyneema®Webbing	.7X.05	Clear Resin	5.4								X																	X		
021-5281	1	S	7	Dyneema®Webbing	.7X.05	Clear Resin	2.8								X							X												



1.0 INTRODUCTION

Thank you for purchasing a Safewaze Self Retracting Lifeline (SRL). This manual must be read and understood in its entirety and used as part of an employee training program as required by OSHA or any applicable state agency. This manual and any other instructional material must be provided to the user(s) of the equipment. The user must understand how to use the SRL safely and effectively, as well as any related Personal Fall Arrest System (PFAS) components.

2.0 APPLICATION

Safewaze SRLs are intended for use as part of a complete personal fall arrest, restraint, work positioning, suspension, or rescue system. Safewaze SRLs are designed for a **single user** whose weight (including clothing, tools, and equipment) is:

ANSI 130-310 lbs. (58.96-140.61 kg)

OSHA Up to 420 lbs. (190.51 kg)

3.0 APPLICABLE SAFETY STANDARDS

Safewaze SRL-Ps conform to the national standard(s) identified on their ID label. Refer to local, state, and federal (OSHA) requirements for additional information concerning the governing of occupational safety regarding Personal Fall Arrest Systems (PFAS). See Figure 12 for examples of product labeling.

When used according to instructions, this product meets ANSI Z359.14-2021, OSHA 1910.140, 1910.66.

Applicable standards and regulations depend on the type of work being done, and also might include state-specific regulations. Refer to local, state, and federal (OSHA) requirements for additional information concerning the governing of occupational safety regarding Personal Fall Arrest Systems (PFAS).

TABLE 2 - ANSI STANDARDS

ANSI	Z359.14-2021	Safety Requirements for Self-Retracting Devices for Personal Fall Arrest and Rescue Systems
------	--------------	---

American National Standards Institute (ANSI) and Occupational Safety and Health Administration (OSHA):

The SRLs covered in this manual meet ANSI Z359.14-2021, and Occupational Safety and Health Administration (OSHA) regulations 1910.140, 1910.66. ANSI requires SRLs be classified according to their intended use and are tested either as Class 1 or Class 2 units. Dynamic performance testing begins by installing the SRL in a controlled test environment. With the SRL attached to a suitable anchorage, the lifeline constituent is attached to a test weight. The weight is then dropped to simulate a fall arrest event. **NOTE: SRL must be tested in all installation configurations allowed per its user instructions.** Test results are recorded.

Parameters recorded are:

- Arrest Distance (AD)
- Average Arrest Force (AAF)
- Maximum Arrest Force (MAF)

The Arrest Distance is the total vertical distance required to completely arrest a fall. The Arrest Distance includes the deceleration distance and the activation distance. The Average Arrest Force is the average of the forces applied to the body and the anchorage by the fall protection system. The Maximum Arrest Force is the maximum amount of force that may be applied to the body and the anchorage by the fall protection system. These tests are conducted in ambient conditions. The units must also be tested in extreme atmospheric conditions. There are three conditions: Cold, Hot, and Wet (Units saturated in water and tested). Separate units may be used for each test. All test results are recorded. This test data is then used to establish the fall clearance guidelines published in this user instruction manual.

Class 1 and 2:

Class 1: Self-retracting devices which shall be used only on overhead anchorages and shall be subjected to a maximum free fall of 2 feet (0.6 m) or less, in practical application.

Class 2: Self-retracting devices which are intended for applications wherein overhead anchorages may not be available or feasible and which may, in practical application, be subjected to a free fall of no more than 6 feet (1.8 m) over an edge.

When the SRL is anchored overhead of the user, ANSI Z359.14-2021 specifies that both Class 1 and Class 2 SRLs shall have an arrest distance of less than 42 in. (1.1 m). Average arrest forces must not exceed 1,350 lbs. (612.35 kg). Conditioned testing of the units allows slightly higher Average Arrest Forces of 1,575 lbs. (714.41 kg), but Maximum Arrest Forces must always remain below 1,800 lbs. (816.47 kg).

When dynamically tested in accordance with requirements of ANSI Z359.14-2021, Class 1 and Class 2 Self-Retracting Devices must have an AAF of 1,350 lbs. (612.35 kg) or less, and an AD of less than 42 in. (1.1 m).

Class 2 SRL labels must include fall clearance table illustrations that include a diagram of the axes shown on the table. These labels shall be affixed to the product. Please see Section 10 of this user instruction manual for how to calculate your Minimum Required Fall Clearance (MRFC) using the affixed labels.

Classification information found on product labels is based on test results. Table 1 indicates the SRLs covered in this manual. NOTE: Arrest distance is one of several parts of the Minimum Required Fall Clearance (MRFC). MRFC is discussed in detail in Section 10. OSHA requires an SRL limit the free fall to 2 feet (0.6 m) or less. If the maximum free fall distance must be exceeded, the employer must document, based on test data, that the maximum arresting force will not be exceeded, and the personal fall arrest system will function properly.

4.0 WORKER CLASSIFICATIONS

Understand the definitions of those who work in proximity of or may be exposed to fall hazards or rescues.

Qualified Person: "Qualified Person" means one who, by possession of a recognized degree, certificate, or professional standing, or who by extensive knowledge, training, and experience, has successfully demonstrated his ability to solve or resolve problems relating to the subject matter, the work, or the project.

Competent Person: "Competent Person" means one who is capable of identifying existing and predictable hazards in the surroundings or working conditions which are unsanitary, hazardous, or dangerous to employees, and who has authorization to take prompt corrective measures to eliminate them.

Authorized Person: "Authorized Person" means a person approved or assigned by the employer to perform a specific type of duty or duties or to be at a specific location or locations at the job site.



It is the responsibility of a Qualified or Competent person to supervise the job site and ensure safety regulations are complied with.

5.0 TRAINING

This equipment is intended to be used by persons trained in its correct application and use. It is the responsibility of the user to assure they are familiar with these instructions and are trained in the correct care and use of this equipment. Users must be aware of the operating characteristics, application, limits, and the consequences of improper use.

6.0 LIMITATIONS AND REQUIREMENTS

When installing or using this equipment always refer to the following requirements and limitations:

- **Capacity:** Safewaze Self Retracting Lifelines are designed in compliance with ANSI Z359.14-2021 to meet the weight capacity range of (130-310 lbs), OSHA up to (420 lbs).
- **Anchorage:** Anchorages selected for fall arrest systems shall have a strength capable of sustaining static loads applied in the directions permitted by the system of at least:
 1. 5,000 lbs. (2267.9 kg) for non-certified anchorages, or
 2. Two times the maximum arresting force for certified anchorages.

When more than one fall arrest system is attached to an anchorage, the strengths set forth in (1) and (2) above shall be multiplied by the number of systems attached to the anchorage.

From OSHA 1926.502 and 1910.66:

Anchorages used for attachment of personal fall arrest systems shall be independent of any anchorage being used to support or suspend platforms, and capable of supporting at least 5,000 lbs. (2267.9 kg) per user attached, or be designed, installed, and used as part of a complete personal fall arrest system which maintains a safety factor of at least two, and is under the supervision of a qualified person.

- **Locking Speed:** The nature of this equipment requires sufficient space in the working area to allow for the SRL to lock. Working in small or confined spaces may keep the user's body from reaching the speed needed to lock the SRL during a fall. Working on slowly shifting materials, such as grain or sand, may not allow the speed needed to cause the SRL to lock.
- **Free Fall:** Safewaze SRLs when used correctly with the unit anchored directly overhead and no slack in the lifeline, will limit the free fall distance to 0 ft. (0 m). In order to limit free fall distances, keep attachment of the SRL below Dorsal D-ring height to as minimal a distance as possible. Safewaze **Latitude Pro SRL-Ps** are not designed to allow for foot level tie-off.
- **Swing Falls:** As the user moves laterally away from an overhead anchor point, the risks related to swing falls increase. The force of striking an object involving swing fall can in some instances generate more forces than a fall with the user wearing no fall protection equipment. Minimize swing falls by working as directly below the anchorage point as possible.
- **Fall Clearance:** Figure 2 Illustrates a Fall Clearance Calculation. Fall Clearance (FC) is the total combined values of Free Fall (FF), Deceleration Distance (DD), and a Safety Factor (SF). Safety Factor calculations may differ by manufacturer, but for the purposes of this manual, the Safety Factor is calculated at 2 ft.. The Safety Factor includes D-ring shift and Harness Stretch.

Table 6-10 in this manual indicate Minimum Fall Clearances when the **Latitude Pro SRL-Ps** are anchored overhead, or below the Dorsal D-ring. For falls from a kneeling or crouched position an additional 3 ft. (1 m) of Fall Clearance is required. If a Swing Fall Hazard exists, the total vertical fall distance will be greater than if the user had fallen directly under the anchor point. Section 11 and Table 10 in this manual provide information regarding Swing Fall hazards and additional Fall Clearance Requirements.

- **Hazards:** Extra precautions should be taken if this equipment is used in an environment where hazards exist. Hazards can include but are not limited to: moving machinery, high voltage equipment or power lines, caustic chemicals, corrosive environments, toxic or explosive gases, or high heat. Avoid working in an area where overhead equipment or personnel could fall and contact the user, fall protection equipment, or the lifeline. Areas where the user's lifeline may cross or tangle with the lifeline of another user should be avoided. Do not allow the lifeline to pass under arms or between the user's legs.
- **Sharp Edges:** Safewaze **Class 1 SRLs** are NOT designed for use in Leading Edge Environments. Should a specific work area have extremely sharp edge(s) that may come into contact with the lifeline constituent of the SRL, a Class 2 SRL is required.

7.0 INSPECTION FREQUENCY

Either the Authorized Person¹ (User) or the Rescuer² must inspect this equipment prior to each use. The Inspection table (Table 3), should be used to determine proper inspection frequency. The Inspection Form (Page 18) describes proper inspection procedures. The Competent Person should record inspection results in the Inspection Form and retain a copy for records. (NOTE: User is advised to make copies of the Inspection Form on (Page 18) of this manual prior to filling out the form for the first time). Copies of the Inspection Form can be used for later Inspections. Annual inspections by a Competent Person other than the user must be recorded in the Inspection Log (Page 19).

1. **Authorized Person:** A person assigned by the employer to perform duties at a location where such person will be exposed to a fall hazard.
2. **Rescuer:** Person or persons other than the rescue subject acting to perform an assisted rescue by operation of a rescue system.



NOTE: Special rescue measures may be required for a fall over an edge.

TABLE 3 - INSPECTION SCHEDULE PER ANSI Z359.14-2021

Type of Use	Application Examples	Conditions of Use	Inspection Frequency Competent Person
Infrequent to Light	Rescue and Confined Space, Factory Maintenance	Good Storage Conditions, Indoor or Infrequent Outdoor Use, Room Temperature, Clean Environments	Annually
Moderate to Heavy	Transportation, Residential Construction, Utilities, Warehouse	Fair Storage Conditions, Indoor and Extended Outdoor Use, All Temperatures, Clean or Dusty Environments	Semi-Annually to Annually
Severe to Continuous	Commercial Construction, Oil and Gas, Mining	Harsh Storage Conditions, Prolonged or Continuous Outdoor Use, All Temperatures, Dirty Environment	Quarterly to Semi-Annually

8.0 PURPOSE

Self Retracting Lifelines are used as part of a PFAS. Safewaze SRLs are designed to safely arrest the user in a fall from height, while minimizing forces associated with what can be an extremely violent event. Safewaze SRLs are authorized for use with Horizontal Lifeline Systems but must NEVER be used as the lifeline constituent of an HLL System. Class 1 SRLs are designed for overhead applications. Class 2 SRLs are designed for both overhead and below Dorsal D-ring use. Maximum allowable Free Fall for Class 1 SRLs is 2 ft..

9.0 SPECIFICATIONS

Latitude Pro SRL-P Minimum Breaking Strength	3,600 lbs. (1632.9 kg)
Working Temperature Range	-35°F (-37°C) to 130°F (54°C)

TABLE 4 - MATERIALS

HOUSING	Clear Resin
DRUM	Aluminum and Plastic
LIFELINE	Dyneema® Webbing
SWIVEL	Steel
FASTENERS	Aluminum / Steel / Stainless Steel
LOCKING PAWLS	Stainless Steel
MAIN SHAFT	Steel
SPRINGS	Stainless Steel

SRLs documented in this instruction manual meet the following Arrest Force and Arrest Distance maximums when tested in accordance with ANSI Z359.14-2021. These calculations are based upon overhead anchorage of the SRL.

TABLE 5 - PERFORMANCE REQUIREMENTS PER ANSI Z359.14-2021 (CLASS 1 SRL)

Average Arresting Force	≤ 1,350 lbs. (612.3 kg)
Maximum Arresting Force	≤ 1,800 lbs. (816.5 kg)
Maximum Arrest Distance	42 in. (106.6 cm)

10.0 ACTUAL ARREST DISTANCE / MINIMUM REQUIRED FALL CLEARANCE

Personal Fall Arrest: Safewaze Class 1 SRLs can be used as part of a complete Personal Fall Arrest System (PFAS) for a maximum of one user. Only one user may be connected to an SRL. Avoid sharp and/or abrasive edges. If contact with an abrasive surface is unavoidable, proper edge protection must be used. The structure utilized for attachment must be capable of withstanding a load of 5,000 lbs. in all directions permitted by the system. The maximum allowable free fall is 2 ft.

Actual Arrest Distance (AD):

Safewaze SRLs are tested in accordance with ANSI Z359.14-2021 conditioning test protocols. Table 6 reflects the actual performance of each unit in the Latitude Pro SRL-P series when subjected to Ambient, Wet, Hot, and Cold testing. The Fall Clearance specifications in Table 8 of this manual reflect the ANSI Z359.14-2021 Maximum Arrest Distance allowance of 42". Actual Arrest Distances for each unit in the Latitude Pro SRL-P series are indicated below. These Actual Arrest Distances are typically lower than the 42" maximum as specified per ANSI. In certain instances this may allow for a Qualified Person to adjust Minimum Required Fall Clearances indicated in Table 8.

TABLE 6 - ANSI ABOVE D-RING ACTUAL ARREST DISTANCES

Model	Ambient	Wet	Hot	Cold
Latitude Pro Series SRL	22"	21"	22"	23"
Latitude Pro Tie-back Series SRL	22"	21"	22"	23"

Minimum Required Fall Clearance:

The Minimum Required Fall Clearance distances indicated in Table 7 are based upon Ambient, Wet, Hot, and Cold testing results for each unit in the Latitude Pro SRL-P series. Fall Clearances indicated in Table 7 are calculated using the greatest Actual Arrest Distance out of the four tests performed. Table 6 indicates the specific arrest distance in prescribed condition testing with 0' offset.


EXAMPLE: The Latitude Pro SRL-Ps have Actual Arrest Distances of 22", 21", 22", and 23" during Ambient, Wet, Hot, and Cold testing respectively. By using the greatest distance (Cold=23") out of the four tests performed and inserting that value in Row B of the Chart in Figure 2, a Total Fall Clearance of 5' 11" is required.

TABLE 7 - ANSI ABOVE D-RING MINIMUM REQUIRED FALL CLEARANCE (MRFC)

Model	MRFC
Latitude Pro Series SRL	5' 11" (1.8 m)
Latitude Pro Tie-back Series SRL	5' 11" (1.8 m)

NOTE: A Qualified Person must determine if MRFCs can be adjusted based upon actual jobsite atmospheric conditions or additional factors.

FIGURE 1 - CLASS 1 SRL AXES DIAGRAM



Fall Clearance: There must be sufficient clearance below the anchorage connector to arrest a fall before the user strikes the ground or an obstruction. Figure 2 illustrates a typical Fall Clearance calculation based on the ANSI Z359.14-2021 prescribed Maximum Allowed Free Fall of 24 in. and Maximum Allowed Arrest Distance of 42 in. Fall Clearance calculations may vary dependent upon the SRL being used. It is essential that the correct Arrest Distance is used to determine Minimum Required Fall Clearance.

**FIGURE 2 - EXAMPLE MINIMUM REQUIRED FALL CLEARANCE CALCULATION
(CLASS 1 SRL)**

Latitude Pro SRL-P Minimum Required Fall Clearance		
A	24" (61 cm)	Maximum Allowed Free Fall per ANSI Z359.14-2021
B	42" (107 cm)	Maximum Allowed Arrest Distance per ANSI Z359.14-2021
C	24" (61 cm)	Safewaze Safety Factor
D	7' 6" (2.3 m)	Sub-Total for Minimum Required Fall Clearance
E	0	*Additional Fall Clearance for Swing Fall (If swing fall hazard exists refer to Table 10)
F	7' 6" (2.3 m)	Total Fall Clearance Required




TABLE 8 - ANSI ABOVE D-RING MINIMUM REQUIRED FALL CLEARANCE BASED ON MAX ARREST DISTANCE OF 42"

		Lateral Offset Distance (Y) In Feet								
		0	2	4	6	8	10	15	20	25
SRL Anchorage Height Above Dorsal D-ring (X) In Feet	8	7' 6" (2.3 m)	8' 3" (2.5 m)	9' (2.7 m)	10' 1" (3.1 m)	11' 4" (3.5 m)	12' 9" (4 m)	17' 1" (5.2 m)	21' 6" (6.6 m)	26' 3" (8 m)
	10	7' 6" (2.3 m)	8' 3" (2.5 m)	8' 9" (2.7 m)	9' 8" (3 m)	10' 9" (3.3 m)	12' 2" (3.7 m)	16' 1" (5 m)	20' 5" (6.2 m)	25' (7.6 m)
	20	7' 6" (2.3 m)	8' 2" (2.5 m)	8' 5" (2.6 m)	9' (2.7 m)	9' 6" (3 m)	10' 5" (3.2 m)	13' 1" (4 m)	16' 4" (5 m)	20' 1" (6.1 m)
	30	7' 6" (2.3 m)	8' 2" (2.5 m)	8' 4" (2.6 m)	8' 7" (2.7 m)	9' 1" (2.8 m)	9' 7" (3 m)	11' 6" (3.5 m)	14' 2" (4.3 m)	17' 2" (5.2 m)
	40	7' 6" (2.3 m)	8' 1" (2.5 m)	8' 3" (2.5 m)	8' 5" (2.6 m)	8' 9" (2.7 m)	9' 3" (2.8 m)	10' 8" (3.3 m)	12' 8" (4 m)	15' 3" (4.7 m)
	50	7' 6" (2.3 m)	8' 1" (2.5 m)	8' 3" (2.5 m)	8' 5" (2.6 m)	8' 9" (2.7 m)	9' 3" (2.8 m)	10' 5" (3.2 m)	12' 2" (3.7 m)	14' 2" (4.3 m)
	60	7' 6" (2.3 m)	8' 1" (2.5 m)	8' 3" (2.5 m)	8' 4" (2.6 m)	8' 6" (2.6 m)	8' 9" (2.7 m)	9' 9" (3 m)	11' 3" (3.4 m)	13' 1" (4 m)
	70	7' 6" (2.3 m)	8' 1" (2.5 m)	8' 3" (2.5 m)	8' 4" (2.6 m)	8' 6" (2.6 m)	8' 8" (2.7 m)	9' 7" (3 m)	10' 9" (3.3 m)	12' 4" (3.8 m)
		Minimum Required Fall Clearance (Z) In Feet								

Specific models of the Latitude Pro SRL-P series are designed and tested for use below the Dorsal D-ring. The user must account for additional clearance requirements when the anchor point is located below the D-ring. Safewaze Latitude Pro SRL-Ps meet all ANSI Z359.14-2021 requirements for a Class 1 SRL when anchored overhead. When anchored below the Dorsal D-ring, Latitude Pro SRL-Ps are compliant with OSHA 1910.140 and OSHA 1910.66.

Table 9 indicates the Minimum Required Fall Clearance (MRFC) for each type of SRL in the Latitude Pro line. Table 9 also provides the Maximum Allowed Distance below the D-ring a Latitude Pro SRL-P may be used, as well as the Actual Arrest Distance as tested for each unit. Both are factored into the MRFC calculation.


TABLE 9 - OSHA BELOW D-RING USE FALL CLEARANCES			
Model	Use Below D-ring	Actual Arrest Distance	Minimum Required Fall Clearance (MRFC)
7' Web	2'	23.6"	8'
7' Web (Tie-Back)	See Figure 3	23.6"	8'



NOTE: Minimum Required Fall Clearances indicated in Table 9 DO NOT account for potential Swing Fall hazards. If Swing Fall hazards exist, they must be factored into any MRFC calculation.

FIGURE 3 - TIE-BACK SRL OPERATION

Figure 3 illustrates typical Latitude Pro 20" Tie-Back SRL anchorages and connections. Safewaze Latitude Pro Tie-Back SRLs can be connected to an anchor point from 9.5" to 21" in diameter. Select an anchorage location with minimal free fall and swing fall hazards. Select a rigid anchorage point capable of sustaining static loads as defined in Section 6. Depending on the Tie-Back circumference, Latitude Pro SRL-Ps can be used below D-ring per OSHA requirements. See diagrams below for examples.




NOTE: Figure 3 represents Maximum Tie-Back webbing length of 20". Certain Tie-Back models (not covered in this manual) have Tie-Back webbing in excess of 20". Refer to specific instructions for units not covered in this manual.

11.0 SWING FALLS




An anchorage point located in a position that is not directly over the user's fall location results in a Swing Fall (See Figure 4). Swing falls may result in the user striking an object with enough force to cause serious injury. Greater clearance is needed to ensure safety during a swing fall as vertical fall distance will be greater than a fall originating directly below the anchorage point. For help determining additional required fall clearance due to Swing Fall, (See Table 10).


FIGURE 4 - SWING FALLS



WARNING: The risk of striking an object or obstruction is dramatically increased during a swing fall. Failure to comply with this warning may result in serious injury or death.

TABLE 10 - ADDITIONAL FALL CLEARANCE FOR SWING FALL HAZARDS (OVERHEAD USE)

 Allowable Work Zone	 Allowable Work Zone with Enhanced Caution	 Not Allowed Work Zone
<p>Using Table 10: Table 10 provides the ability for the user to determine additional fall clearance requirements if a Swing Fall Hazard is present when using the a Latitude Pro SRL-P in an overhead application. The Y-Axis represents the height the SRL is anchored above the user's Dorsal D-ring. The X-Axis represents lateral movement of the worker in relation to the SRL.</p> <p>Example - Latitude Pro SRL-P Anchored Overhead: This example represents the user anchored 5' Overhead (Up along the Y Axis) and 4' Laterally (Along the X Axis). The intersection of these distances on the chart indicate an additional 1' of fall clearance required. This additional required fall clearance must be added to total fall clearance calculations.</p>		



12.0 FALL PROTECTION AND RESCUE PLAN

When using this equipment, employers must create and maintain a Fall Protection and Rescue Plan and provide the means to implement those plans. The plans must be communicated to equipment users, authorized persons, and rescuers. These plans must meet ANSI Z359.2 "Minimum Requirements for a Comprehensive Managed Fall Protection Program." They should include the requirements and guidelines for the employer's managed Fall Protection Program. This would include eliminating and controlling fall hazards, duties and training, policies, fall protection procedures, rescue procedures, incident investigations, and evaluation of the program's effectiveness.

13.0 NORMAL OPERATIONS

During normal operations, the lifeline constituent of the SRL will extend and retract freely with no slack or hesitation as the worker moves at normal speeds. In the event of a fall, Safewaze SRLs are equipped with a speed sensing braking system. The braking system will activate, stopping the fall, and absorbing much of the energy created by the fall. Due to the speed sensing braking system, user(s) should avoid quick or sudden movements, as this may cause the SRL to inadvertently lock. If the user is performing operations near the end of the working length of the SRL, a reserve line is incorporated within the SRL to reduce fall arrest forces.

14.0 COMPATIBILITY OF COMPONENTS

Safewaze Fall Protection Equipment is designed for use with Safewaze components and subsystems only. A Qualified Person should make the determination of Safewaze equipment compatibility with equipment not manufactured by Safewaze. Replacement or substitution of equipment not manufactured by Safewaze, may degrade, or reduce the safety and reliability of the complete system.




IMPORTANT: Read and follow manufacturer's instructions for associated components and subsystems in your personal fall arrest system.

15.0 COMPATIBILITY OF CONNECTORS

Connectors are compatible with connecting elements when they have been designed to work together in such a way that their sizes and shapes do not cause their gate mechanisms to inadvertently open, regardless of how they become oriented. Connectors (hooks, carabiners, and D-rings) must be capable of supporting at least 5,000 lbs. (2267.9 kg). Connectors must be compatible with the anchorage or other system components (See Figure 5). Do not use equipment that is not compatible. Non-compatible connectors may unintentionally disengage (See Figure 5). Connectors must be compatible in size, shape, and strength. Self-locking snap hooks and carabiners are required by ANSI Z359 and OSHA guidelines. Contact Safewaze if you have any questions about compatibility.

FIGURE 5 - UNINTENTIONAL DISENGAGEMENT



NOTE: SOME SPECIALTY CONNECTORS HAVE ADDITIONAL REQUIREMENTS. CONTACT SAFEWAZE WITH QUESTIONS.

Using a connector that is undersized or irregular in shape (1) to connect a snap hook or carabiner could allow the connector to force open the gate of the snap hook or carabiner. When force is applied, the gate of the hook or carabiner presses against the non-complaint part (2) and forces open the gate (3). This allows the snap hook or carabiner to disengage (4) from the connection point.

15.1 MAKING CONNECTIONS

Snap hooks and carabiners used with this equipment must be double locking and/or twist lock. Ensure all connections are compatible in size, shape and strength. Do not use equipment that is not compatible. Ensure all connectors are fully closed and locked.


Safewaze connectors (snap hooks and carabiners) are designed to be used only as specified in each product's user's instructions. (See Figure 6) for examples of inappropriate connections. Do not connect snap hooks and carabiners:

- To a D-ring to which another connector is attached.
- In a manner that would result in a load on the gate (with the exception of Tie-Back hooks). NOTE: Large snap hooks must not be connected to objects which will result in a load on the gate if the hook twists or rotates, unless the snap hook complies with ANSI Z359.12 and is equipped with a 3,600 lbs. (1632.9 kg) gate. Check the marking on your snap hook to verify its compatibility.
- In a false engagement, where features that protrude from the snap hook or carabiner catch on the anchor, and without visual confirmation seems to be fully engaged to the anchor point.
- To each other.
- By wrapping the lifeline around an anchor and securing to lifeline except as allowed for Tie-Back models
- To any object which is shaped or sized in a way that the snap hook or carabiner will not close and lock, or that roll-out could occur.
- In a manner that does not allow the connector to align properly while under load.



NOTE: Large throat snap hooks must not be connected to standard size D-rings or similar objects which will result in a load on the gate if the hook or D-ring twists or rotates, unless the snap hook complies with ANSI Z359.12 and is equipped with a 3,600 lbs. (1632.9 kg) gate. Check the marking on your snap hook to verify that it is appropriate for your application.

FIGURE 6 - INAPPROPRIATE CONNECTIONS



16.0 USE



WARNING: Contact Safewaze if you have questions regarding compatibility of this equipment that are not covered in this manual. Do not alter or misuse this equipment. Some subsystem components could affect the performance of the operation of this equipment. Do not anchor this product to moving machinery, hazards that include chemical, electrical or gaseous characteristics. Failure to comply with this warning could result in injury or death.



WARNING: Consult your doctor if there is reason to doubt your fitness to safely absorb the shock from a fall arrest. Age and fitness seriously affect a worker's ability to withstand falls. Pregnant women or minors must not use Safewaze SRLs. Failure to heed this warning may result in serious injury or death.

16.1 OPERATION

Inspect the SRL as described in Section 19, before using the equipment. Refer to Figure 7 for common system connections used with SRL applications. Mount the SRL to an approved anchor point. Ensure connections are compatible in size, shape, and strength. Ensure hooks are fully closed and locked. When the worker is fully attached, the worker is then free to move about within the recommended working area. If a fall occurs, the SRL will lock and arrest the fall. Upon rescue, remove the SRL from use. When working with an SRL, always allow the lifeline to retract back into the device in a controlled manner. Do not release the unit to "free-spin" back into itself.



WARNING: Do not tie or knot the lifeline. Avoid lifeline contact with sharp or abrasive surfaces. Inspect the lifeline frequently for cuts, fraying, burns, or signs of chemical damage. Dirt, contaminants, and water can lower performance of the lifeline. Use caution near power lines. Failure to comply with this warning may result in serious injury or death.

16.2 AFTER A FALL

As discussed in Section 12, employers must create and maintain a Fall Protection and Rescue Plan and provide the means to implement those plans. ANSI Z359.2 "Minimum Requirements for a Comprehensive Managed Fall Protection Program" specifies "The employer shall provide prompt rescue to all fallen authorized persons", with a recommended goal for rescue subject contact of less than 6 minutes. While there is no specific criteria for what constitutes a "prompt rescue", all workers must be trained on the site Rescue Plan, and all equipment associated with the Rescue Plan.

Any equipment exposed to the force of a fall, or that shows damage consistent with the effects of a fall, must be removed from service immediately. Equipment must then be serviced (See Section 18) if applicable, or disposed of (See Section 19).

16.3 BODY SUPPORT

A full body harness must be worn when using Safewaze SRLs.

16.4 SYSTEM CONNECTIONS

Figure 7 illustrates some typical examples of harness and anchorage connections for Latitude Pro SRL-Ps. When using a snap hook to make a connection, ensure roll-out cannot occur (See Figure 5). Do not use snap hooks or carabiners that will not completely close over the anchor point. This includes traditional overhead anchor point tie-off, housing attachment to dorsal D-ring, and 100% tie-off. Follow the manufacturer's instructions supplied with each system component.



WARNING: Never connect the snap hook of one SRL to the lifeline of another SRL or lanyard. Failure to comply with this warning may result in equipment malfunction, serious injury or death.

FIGURE 7 - SYSTEM CONNECTIONS





FIGURE 8 - SW-9012 BWB INSTALLATION




The SW-9012 Behind the Web Bracket (BWB) comes fully assembled and ready for installation. No tools are required for installation of the BWB onto a Full Body Harness (FBH) harness. Use the following instructions and Figure 8 to install the 9012 BWB.

Connect To Harness:

1. Ensure that the curved portion of BWB is in a downward orientation relative to the harness (See Step 1).
2. Simultaneously depress both locking buttons (A) and (B) and slide the bracket open as indicated (See Steps 2 and 3)
3. With the bracket open, position the bar assembly in an orientation that will allow the bar to slide under/behind both web loops at the Dorsal D-ring of the FBH.
4. While pressing in on locking button (A) slide the bar behind both loops of webbing at dorsal D-ring until the bar locks back into place (See Step 4).
5. Check the locking function of the bracket by attempting to slide the bracket open WITHOUT depressing locking buttons (A) or (B). Bracket bar should not move and the bracket is now locked into place.

FIGURE 9 - 9013 BWB INSTALLATION



The 9013 brackets comes fully assembled and ready for installation. No tools are required for installation of the bracket onto harness. Use the following instructions and Figure 9 to install the 9013 Behind the Web Bracket.

Connect To Harness:

1. Ensure that the curved portion of 9013 is in a downward orientation relative to the harness (See Dwg. 1).
2. Simultaneously depress both locking button (A) and and slide lock (B) (See Dwg. 2) to swing the bracket open as indicated (See Dwg. 3).
3. With the bracket open, install dual leg retractables onto the bracket via the swivel tops of each. Swivels should be hanging on the curved portion of bracket.
4. Slide the bar behind both loops of webbing at dorsal D-ring. Swing the bracket closed until it locks into place.
5. Check the locking function of the bracket by attempting to swing the bracket open WITHOUT depressing locking button (A) or slide lock (B). Bracket bar should not move and the bracket is now locked into place.
6. Dual leg Retractable can be easily installed and removed from bracket by once again depressing both locking button (A) and slide lock (B), which allows bracket to swing open without complete removal from harness.

FIGURE 10 - FS1014-TL-BLACK-BWB INSTALLATION



The behind the web bracket comes fully assembled and ready for installation. No tools are required for installation of the bracket onto harness. Use the following instructions and Figure 10 to install the bracket:

Connect to Harness:

1. Unfasten the two small brackets on the green retractable spacer off of the carabiner.
2. Slide the green spacer around to the side of carabiner to allow opening of the carabiner gate.
3. Open the carabiner gate and slide spacer off of carabiner and remove one of the retractables.
4. Holding gate open on carabiner, insert the open end of carabiner through the webbing loops at the Dorsal D-ring of the harness. Ensure that both loops of webbing on are captured inside of carabiner.
5. With carabiner gate still open, slide the removed retractable and green spacer back onto carabiner and allow carabiner gate to close.
6. Slide the green retractable spacer back over the gate of carabiner and snap the two small brackets back into place on carabiner, with the web loops positioned between the ends of the bracket.

16.5 ANCHORAGE

Select an anchorage location with minimal free fall and swing fall hazards. Select a rigid anchorage point capable of sustaining static loads as defined in Section 6. ANSI compliant when used overhead. OSHA compliant when used below the D-ring.



IMPORTANT: Do not allow the lifelines to pass under arms or between legs.

17.0 PERFORMANCE

Safewaze SRLs have been tested and certified to the performance requirements of the standard(s) identified on their ID labels. See Figure 12 for examples of product labeling.

18.0 MAINTENANCE, SERVICE, AND STORAGE

18.1 MAINTENANCE

Cleaning procedures for Safewaze SRLs are as follows:

Periodically clean the exterior of the SRL using water and a mild soap solution. Clean labels to maintain readability.

An excessive buildup of debris on the webbing of the SRL may prevent the lifeline from fully retracting back into the housing. Improper retraction of the lifeline constituent of the SRL could create a potential free fall hazard.

Clean web lifeline with mild soap solution and water. Allow web lifeline to air dry completely before retracting back into the housing. **DO NOT USE HEAT** to dry web lifeline.



IMPORTANT: If the lifeline comes in contact with acids or other caustic chemicals, remove the SRL from service and wash with water and a mild soap solution. Inspect the SRL (using the Inspection Form on Page 18) before returning to service.

18.2 SERVICE

Only Safewaze or entities authorized in writing by Safewaze, shall make repairs to this equipment. Remove the SRL from use if the SRL has been subjected to fall arrest forces or has been used to affect a rescue. If unrepairable dispose of the SRL as recommended in Section 19. For questions regarding disposal, service, or repair of Safewaze SRLs, contact Safewaze at (800) 230-0319.

18.3 STORAGE

Store Safewaze SRLs in a cool, dry, clean environment out of direct sunlight. Avoid areas where chemical vapors may exist. Thoroughly inspect the SRL after any period of extended storage.

19.0 INSPECTION

19.1 PRIOR TO EACH USE


Before each use ensure that the equipment is in good working condition. Inspect the unit to ensure it has not been damaged and that the unit pays out and retracts properly. Prior to each use, the braking system must be inspected. Grasp the body of the unit in one hand and the web in the other. With a quick, jerking motion, pull down on the webbing. The brake should engage, stopping movement almost immediately. Inspect the web (using the Inspection Form on Page 18) and ensure that all connection hardware is working properly. Brake failure or unsatisfactory results during any portion of the inspection requires immediate removal of the SRL from service. Figure 13 points out key inspection areas of the Latitude Pro series of SRLs.

19.2 UNSAFE OR DEFECTIVE CONDITIONS


Figure 11 shows examples of equipment damage. Equipment inspectors must be trained to look for damage as illustrated in Figure 11, as well as other damage that may occur. If inspection reveals an unsafe or defective condition remove the SRL from service.

FIGURE 11 - EXAMPLES OF EQUIPMENT DAMAGE

Webbing Damage Examples




Frayed



Welding Burns



Heavily Soiled




Cut

19.3 PRODUCT LIFE

The working life of Safewaze SRLs are determined by work conditions, care, maintenance, and proper inspections. As long as the SRL passes inspection, it may remain in service.

FIGURE 13 - INSPECTION DIAGRAMS



Manufacturer: _____

Model Number: _____

Description: _____

Serial Number: _____

Lot Number: _____

Date of Manufacture: _____

Company: _____

Name of Inspector: _____

Signature: _____

Date of Inspection: _____

In-Service Date: _____

Lifeline Material: ☐ Galvanized Steel ☐ Stainless Steel ☐ Web

LABELS & MARKINGS

	PASS	FAIL	NOTE
Label (Intact and Legible)			
Appropriate ANSI / OSHA / CSA Markings			
Inspections are Current / Up-to-Date			
Date of First Use			

SHOCK PACK (IF PRESENT)

	PASS	FAIL	NOTE
Cover / Shrink Tube (Don't Cut or Remove)			
Damage / Fraying / Broken Stitching			
Impact Indicator (Signs of Deployment)			

HOUSING

	PASS	FAIL	NOTE
Attachment Point			
Nuts / Bolts / Rivets / Screws			
Evidence of Damage (Dents / Cracks / Rust)			

LIFELINE (WEB OR CABLE)

	PASS	FAIL	NOTE
Termination (Stitch, Splice, or Swage)			
Cuts / Fraying / Broken Stitching			
Excessive Wear			
Cable Separating / Bird-Caging			
Entire Length Retracts Smoothly			
Test Braking / Locking Function			

CONNECTORS

	PASS	FAIL	NOTE
Connector (Self-Closing & Locking)			
Impact Indicator			
Hook Body / Rivets			
Corrosion			
Pitting / Nicks			

SELF-RETRACTING DEVICES



NOTES



INSPECTION LOG

[illegible]



Safewaze
225 Wilshire Ave SW
Concord, NC 28025

PHONE: 1-800-230-0319
FAX: 1-704-262-9051

WEB: safewaze.com
EMAIL: info@safewaze.com