

# 2024-11-25 Things to know about Double Insulated Tools

In a previous toolbox talk we discussed why we should never use a tool or extension cord when the grounding pin on the plug has been damaged or removed. However, you are probably aware that not all tools are made with a grounding pin on the plug; instead, it may have only two prongs on the plug, with one being a little wider than the other (refer to the handout for an example). But that does not necessarily mean the tool is unsafe to use, it could be a double insulated tool.

As we discussed before, many hand tools and other pieces of equipment that are equipped with electrical cords are manufactured with casings or housings made from metal or other materials that conduct electricity. And if one of the insulated conductor wires encased within the power cord becomes loose inside the tool or equipment, it could touch the casing or housing and cause it to become energized. Subsequently, anyone who then touches that energized tool or equipment's casing or housing could be electrocuted.

But a double insulated tool is made differently. It does not have a casing or housing made from conductive material. Instead, it is made of plastic or some other material that does not conduct electricity. This extra layer of electrical insulation provided by the non-conductive casing or housing negates the need for a grounding wire and prong on the power cord. You can tell if the tool you are using is a double-insulated variety. Just look at the manufacturer's data plate or sticker affixed to the tool, and if it is double insulated and you may see the words "Double Insulated" printed there. Or you may see the international symbol for a double insulated tool on the label; it is a "square-within-a-square" symbol (refer to handout for an example).

And in many cases, you may see both the wording and the box-in-box symbol displayed on the label. But don't think for a minute that using a double insulated tool means you are always going to be protected from electrocution. That is because any breach in the tool's plastic casing or housing creates a potential pathway for electricity to travel through and make contact with your skin. Such conditions can occur if the tool casing or housing is cracked, which can happen if the tool is dropped onto a hard surface. A breach can also occur if any screws or other fasteners that hold the casing or housing parts together become loose and allow them to separate. So always inspect your tools and equipment to make sure their casings and housings are free of damage and secured tightly in place. And if you do happen to come across any tool or equipment with a casing or housing that is damaged or loose, do not use it! Also do not use make-shift fixes such as wrapping the tool casing or housing with electrical tape. Instead, take that tool out of service right away and turn it in to your supervisor or a safety representative.

*By Clicking "Mark as Read" - you are acknowledging you have read this entire (opened appropriate attachments) Toolbox Talk and understand this is company policy and will abide by regulations outlined in this safety policy. Please complete your acknowledgement within 24 hours of release. If you receive this notice, you are REQUIRED to read this content.*

---

Revision #1

Created 2024-11-25 14:58:57 UTC by Dale Bergman

Updated 2024-11-25 14:59:36 UTC by Dale Bergman